


If you are looking to identify a Urmet Handset for replacement

Step 1


Find the small gap usually found at the bottom of the handset, insert a flat head screw driver into the gap and gently twist.

Example (handsets may have different fixings to the example shown)




Step 2

Gently remove the front cover.



Step 3

Identify your replacement audio handset using the terminal connections below.



Audio handsets may have different locations for terminal connections

If your audio handset has the following terminal numbers/letters



The replacement handset is [Part number 1130/11](#)

If your audio handset has the following terminal numbers/letters



The replacement handset is a Miro. [Part number 1150/1](#)

If your audio handset has the following terminal numbers/letters



The replacement handset is a Utopia. [Part number 1138/4](#)

If your audio handset has the following terminal numbers/letters

LINE	CP	S+	S-
------	----	----	----

The replacement handset is a Miro. [Part number 1183/5](#)

Can't find a match?

You can email the terminal numbers/letters or an image of the terminal numbers/letters to:-

Info@securasound.co.uk